



## ADJUSTING THE SCREEN INCLINATION

Press the key the below the display and set the display in your desired position.

