

**REMOVING THE ROLLERBOX/ DRAWER**

Items may become jammed in the base unit. To remove you will need to remove the roller box/lower drawer. Pull the drawer/ roller box towards to by pinching. The draw may not remove if the cartridges are in the front position stopping it.

*(please see how too manually remove the rollerbox)*

